



# FOURTEENTH COLONY LIGHTING

HANDCRAFTED LIGHT FIXTURES MADE IN MEMPHIS, TENNESSEE

**“FOR OUTDOOR INSTALLATION ONLY”**

## INSTRUCTIONS FOR NATURAL GAS CEILING MOUNT

This lantern must be installed by a certified plumber to conform to local codes or in absence of local codes with the national fuel gas code ANSI Z223.1.

 **WARNING**

If you smell gas:

1. Shut off gas to the appliance
2. Extinguish any open flames
3. If odor continues, leave the area immediately
4. After leaving the area, call your gas supplier or fire department

 **WARNING**

DO NOT store or use gasoline or any other flammable vapors or liquids in the vicinity of this, or any other appliance.

Failure to follow these instructions could result in fire or explosion, which could cause property damage or personal injury.

*ATTENTION INSTALLER: Leave these instructions with the appliance so the consumer will retain them for future reference.*

*NOTE: The minimum clearance from combustible constructions is 12" top by 6" side (excluding ornamentation).*

1. Adjust natural gas inlet pressure to 7.0 inches WC.
2. Install brass mounting bracket to the ceiling with the appropriate mounting hardware (not supplied).
3. Reduce gas supply line from ceiling to ¼" aluminum tubing using approved fittings only.
4. Make an aluminum coil using ¼" OD aluminum tubing to allow hook-up of gas supply line to ¼" flare male connector located in ceiling mounting box of lantern. All hook-ups must be made within the depth and height of the lantern mounting box.
5. Attach fixture to brass mounting bracket with screw caps provided.
6. Check for any leaks using a soap solution. If bubbles appear, shut off main gas line and tighten all fittings, then recheck.

### VALVE ADJUSTMENT INFORMATION

The valve has a simple on-off dial. The valve is fully open when turned to the 12 o'clock position and is off when turned to the 3 o'clock position.

To light the burner:

1. Turn thumb dial to the 2 o'clock position.
2. Light burner tip.
3. Adjust flame to desired height.

### CARE AND MAINTENANCE

Turn off the flame and allow the lantern time to cool down before performing any maintenance.

- To clean the lantern, rinse with water then apply a diluted solution of dishwashing liquid with a soft cloth to remove dirt. Rinse again with water.
- To clean the glass on the lantern, use a mild glass solution.
- Keep the holes in the bottom and top of the fixture clear of debris so as not to obstruct the flow of combustion & ventilation air.
- Check burner/pilot flame periodically to make sure it is working properly.
- Keep appliance area clear and free from combustible materials, gasoline and other flammable vapors and liquids.
- Contact Fourteenth Colony Lighting at (800) 297-9719 to obtain replacement parts.

